






















































	Original	Rechange		Original	Rechange
	Power		Power		Right
	Time		3D		Down
	Display		Info		I<< Prev
	Open / Close		Eject		>>I Next
	Angle		Format		<< FR
	Language		Dual		>> FF
	Sub.Title		Subt		Zoom
	Title		Smart		Setup
	Menu / PBC		Menu		L / R
	P / N		TV/R		Repeat
	Return		Back		Mark
	Mute		Mute		Goto
	Play		Play		Pause / Step
	Stop		Stop		Slow
	Up		Up		1
	Left		Left		2
	Enter		Ok		3



