

























Original	Rechange
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 SAT	 Smart
 Tv/R	 TV/R
 Menu	 Menu
 Exit	 Exit
 Up	 Up

Original	Rechange
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 FAV	 Pre Ch
 EPG	 Guide
 V+	 Vol +
 V-	 Vol -
 Info	 Info
 Audio	 Dual
 Text	 Text
 P+	 Ch +
 P-	 Ch -
 Red	 Red
 RCL	 Options
 Green/Pause	 Green
 Yellow	 Yellow





Original		Rechange		Original		Rechange	
	SUB		Subt				
	V.F		3D				
	Blue		Blue				
	Pause		Pause				
	<I		I<<				
	I>		>>I				
	Rec		Rec				
	Play		Play				
	<<		<<				
	>>		>>				
	Stop		Stop				



























Original	Rechange
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 SAT	 Smart
 Tv/R	 TV/R
 Menu	 Menu
 Exit	 Exit
 Up	 Up

Original	Rechange
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 FAV	 Pre Ch
 EPG	 Guide
 V+	 Vol +
 V-	 Vol -
 Info	 Info
 Audio	 Dual
 Text	 Text
 P+	 Ch +
 P-	 Ch -
 Red	 Red
 RCL	 Options
 Green/Pause	 Green
 Yellow	 Yellow









































































Original		Rechange		Original		Rechange	
	SUB		Subt				
	V.F		3D				
	Blue		Blue				
	Pause		Pause				
	<		I<<				
	>		>>I				
	Rec		Rec				
	Play		Play				
	<<		<<				
	>>		>>				
	Stop		Stop				



























Original	Recharge	Original	Recharge
 Power	 Power	 Left	 Left
 Mute	 Mute	 OK	 Ok
 1	 1	 Right	 Right
 2	 2	 Down	 Down
 3	 3	 FAV	 Pre Ch
 4	 4	 EPG	 Guide
 5	 5	 V+	 Vol +
 6	 6	 V-	 Vol -
 7	 7	 Info	 Info
 8	 8	 Audio	 Dual
 9	 9	 Text	 Text
 0	 0	 P+	 Ch +
 SAT	 Smart	 P-	 Ch -
 Tv/R	 TV/R	 Red	 Red
 Menu	 Menu	 RCL	 Options
 Exit	 Exit	 Green/Pause	 Green
 Up	 Up	 Yellow	 Yellow





	Original	Rechange	Original	Rechange
	SUB	 Subt		
	V.F	 3D		
	Blue	 Blue		
	Pause	 Pause		
	<I	 I<<		
	I>	 >>I		
	Rec	 Rec		
	Play	 Play		
	<<	 <<		
	>>	 >>		
	Stop	 Stop		

