



Original	Rechange
Power	Power
Tv/Rad	TV/Radio /
Search/*	Shift + Red / Netflix /
Subtitle	Subtitle / EQ
*	Setup / OPT /
Source	AV / Input / RDS
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
List	Smart / List
0	0

Original	Rechange
.../*	Display / Media
Vol+	Vol+
FAV//Quic Acces/*	Fav / Marker / PC
CH+	CH+ / Page+
Vol-	Vol-
Guide	Guide / EPG / -/-
CH-	CH- / Page-
Mute	Mute / Dimmer
Text	Text / Goto
Home	Menu / Home
T.Opt.	Shift + Setup / OPT / Tools
Back	Back / Return
Up	Up
Exit	Exit / Cancel / Clear
Left	Left
OK	OK
Right	Right



