



Original	Recharge
Power	Power
Input	AV
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Guide	Guide
CH List	List
Red	Red
Green	Green
Yellow	Yellow

Original	Recharge
Blue	Blue
[≡]	Menu
Play	Play
Pause	Pause
Back	Back
Exit	Exit
Up	Up
Down	Down
Right	Right
Left	Left
OK	Ok
Vol+	Vol +
Vol-	Vol -
Mute	Mute
Home	Smart
CH+	Ch +
CH-	Ch -





Original	Recharge	Original	Recharge
Subtitle	Subt		
Info	Info		
TXT	Text		
Music	3D		
Free	Options		
ART	Dual		
Netflix	Shift + Media		
Prime Video	Format		
YouTube	Shift + Smart		
Rakuten TV	TV/R		
Media	Media		
[++]	D. Menu		

Original	Recharge

