






































	Original	Recharge		Original	Recharge
	Power		Power		Play
	Night		Sleep		Pause
	Mute		Mute		>>
	HDMI 1		1		
	HDMI 2		2		
	TV		TV/R		
	Bluetooth		Smart		
	Vol+		Vol +		
	Vol-		Vol -		
	Bass+		Up		
	Bass-		Down		
	Voice+		Ch +		
	Voice-		Ch -		
	Movies		Options		
	Sports		Subt		
	Music		Dual		
	<<		<<		

