







































































Original		Rechange		Original		Rechange	
	Power		Power		[≡◇]		Eject
	i		Info		Sleep		Sleep
	Input Select		AV		Mute		Mute
	Picture Size		Format		Menu		Menu
	1		1		[≡]		Text
	2		2		Up / P+		Up
	3		3		Up / P+		Ch +
	4		4		Down / P-		Down
	5		5		Down / P-		Ch -
	6		6		Right / Vol+		Right
	7		7		Right / Vol+		Vol +
	8		8		Left / Vol-		Left
	9		9		Left / Vol-		Vol -
	0		0		Enter / CH List		Ok
	[≡o] [≡x]/P↔P		3D		Enter / CH List		List
	Audio I/II		Dual		Exit		Exit
	[≡?]		Smart		Freeze / [≡+]		Stop



