



Original		Rechange		Original		Rechange	
	Power		Power		6		6
	Mute		Mute		7		7
	V-Format		Format		8		8
	Sleep		Sleep		9		9
	Text		Text		0		0
	TV / Radio		TV/R		List		List
	Red		Red		Recall		Back
	Green		Green		Menu		Menu
	Yellow		Yellow		Exit		Exit
	Speaker		Dual		Up		Up
	Subtitle		Subt		Left		Left
	Blue		Blue		OK		Ok
	1		1		Right		Right
	2		2		Down		Down
	3		3		Page Down		Shift + Ch -
	4		4		Page Up		Shift + Ch +
	5		5		Vol +		Vol +





Original		Rechange		Original		Rechange	
	Vol -		Vol -		> <	 + 	Shift + Stop
	Info		Info		<<		<<
	CH+		Ch +		>>		>>
	CH-		Ch -		Picture		Media
	FAV		Pre Ch		Bookmark		Options
	Guide		Guide		Next Bookmark		3D
	Zoom		Eject				
	✓		Smart				
	Play		Play				
	Stop		Stop				
	Pause		Pause				
	Rec		Rec				
	►[≡]		D. Menu				
	I>	 + 	Shift + Play				
	<<		<<				
	>>		>>				
	SAT		AV				

