
































































Original		Rechange		Original		Rechange	
	Power On		Power		Up		Up
	Power Off		Shift + Power		Down		Down
	Device On		Shift + Pre Ch		Right		Right
	Device Off		Shift + 0		Left		Left
	Quick Select		Red		Enter		Ok
	Quick Select 2 / (SAT/CBL)		Green		<</Band		<<
	Quick Select 3/(Dock)		Yellow		Play		Play
	CH+		Ch +		>>/Mode		>>
	CH-		Ch -		I<</Tuning		I<<
	Vol+		Vol +		Pause		Pause
	Vol-		Vol -		Stop		Stop
	Mute		Mute		>>I/Tuning Up		>>I
	Source Select		AV		MulteQ		Dual
	Menu		Menu		DYN EQ		Media
	CH Level/Top		Shift + Menu		DYN Vol		Subt
	Search/Setup		Options		Restorer		Exit
	Return		Back		Standard		Text



