







































































Original		Rechange		Original		Rechange	
	Power		Power		8		8
	Night Mode		Rec		9		9
	Tuner Menu		Menu		10/0		0
	Dynamic Bass		List		>10		Guide
	Sleep		Sleep		Function		Smart
	Sound Field-		Ch -		Display		Info
	Sound Field+		Ch +		DVD Setup		Options
	Muting		Mute		Subtitle		Subt
	DVD Menu		D. Menu		Vol+		Vol +
	Clear		Exit		Vol-		Vol -
	1		1		Up		Up
	2		2		Down		Down
	3		3		Right		Right
	4		4		Left		Left
	5		5		Enter		Ok
	6		6		Return		Back
	7		7		Tv/Video		TV/R



