



Original	Recharge
Power	Power
TV	TV/Radio /
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
FAV CH	Shift + Fav / Marker / PC
0	0
PRE CH	Fav / Marker / PC
Info	Info / Angle
Menu	Menu / Home
Guide	Guide / EPG / -/--

Original	Recharge
Tools	Setup / OPT /
Up	Up
Return	Back / Return
Left	Left
Enter	OK
Right	Right
Internet	Smart / List
Down	Down
Exit	Exit / Cancel / Clear
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
Vol+	Vol+
Source	AV / Input / RDS
P +	CH+ / Page+
Vol-	Vol-



