







































	Original	Rechange		Original	Rechange
	Open/Close		Eject		Volume-
	A.Space		AV		Play
	Prog		Smart		Pause
	Direct		Media		Stop
	1		1		L<<
	2		2		>>L
	3		3		All
	4		4		All
	5		5		A-B
	6		6		A-B
	7		7		<<
	8		8		>>
	9		9		
	10		0		
	+10		Guide		
	Call		Pre Ch		
	Volume+		Vol +		

