



Original		Recharge		Original		Recharge	
	Power		Power		Left		Left
	Mute		Mute		OK		Ok
	1		1		Right		Right
	2		2		Down		Down
	3		3		EPG		Guide
	4		4		TV/Radio		TV/R
	5		5		Red		Red
	6		6		Green		Green
	7		7		Yellow		Yellow
	8		8		Blue		Blue
	9		9		Rec		Rec
	0		0		Fav		Pre Ch
	Info		Info		Stop		Stop
	Back		Back		Media		Media
	Menu		Menu		I<<		I<<
	Exit		Exit		>>I		>>I
	Up		Up		>>		>>





	Original	Recharge	Original	Recharge
	<<			<<
	Play			Play
	Pause			Pause
	TTX			Text
	Audio			Dual
	Subtitle			Subt
	USB			Smart
	Timer			AV

