



Original	Recharge
Power On	Power
Standby	Shift + Power
DVI	Shift + 1
Display Port	Shift + 2
VGA	Shift + 3
RGB / HV	Shift + 4
HDMI	Shift + 5
DVD/HD	Shift + 6
VIDEO	Shift + 7
S-Video	Shift + 8
Picture Mode	Shift + Format
Aspect	Format
Sound	Dual
Option	Options
1	1
2	2
3	3

Original	Recharge
4	4
5	5
6	6
7	7
8	8
9	9
0	0
--	Shift + Guide
ENT	Pre Ch
Display	Info
Menu	Menu
Up	Up
Left / -	Left
SET	Ok
Right / +	Right
Down	Down
Auto Set Up	Smart





Original	Recharge	Original	Recharge
 Exit	 Exit		
 Vol+	 Vol +		
 Vol-	 Vol -		
 Guide	 Guide		
 Mute	 Mute		
 CH+	 Ch +		
 CH-	 Ch -		
 Still On/Off	 Stop		
 Still Capture	 Rec		
 [=]	 Text		
 PIP On/OFF	 Red		
 PIP Input	 Green		
 PIP Change	 Yellow		
 MTS	 Media		
 Audio Input	 AV		

Original	Recharge

