



Original	Recharge	Original	Recharge
	Power		Power
	Night		Exit
	Surr		Subt
	OPT		Options
	HDMI In		Smart
	HDMI ARC		Media
	USB		Yellow
	AUX		Red
	Bluetooth/Pairing		Green
	Movie		Blue
	Music		Dual
	TV		TV/R
	Treble+		Ch +
	Treble-		Ch -
	Bass+		Vol +
	Bass-		Vol -
	Mute		Mute

Original	Recharge	Original	Recharge
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Play		Play
	Pause		Pause

