







	Original	Rechange	Original	Rechange
	Power			
	Phono			
	CD			
	Tuner			
	Aux			
	Tape1			
	Tape2			
	Vol+			
	Vol-			
	Mute			

