



Original	Recharge
 Power	 Power
 Auto Setup	 Setup / OPT /
 1/Computer	 1
 1/Computer	 Fav / Marker / PC
 2	 2
 3/DVI-I	 3
 4/Video	 4
 5/Digital Link	 5
 6/HDMI	 0
 6/HDMI	 6
 Menu	 Menu / Home
 Return	 Back / Return
 Up	 Up
 Left	 Left
 Enter	 OK
 Right	 Right
 Down	 Down

Original	Recharge
 Freeze	 Pause / Step / Freeze
 AV Mute	 Mute / Dimmer
 Default	 Text / Goto
 Eco	 Info / Angle
 Func1	 Red / Netflix / Search
 Func2	 Green / APP / Repeat
 Func3	 Yellow / YouTube / Repeat
 ID Set	 Smart / List
 Vol+	 Vol+
 ID All	 Display / Media
 Vol-	 Vol-

