







































































Original		Rechange		Original		Rechange	
	Power		Power		8		8
	Mute		Mute		9		9
	Play		Play		0		0
	Pause		Pause		Recall		Back
	Stop		Stop		EPG		Guide
	Rec		Rec		Menu		Menu
	<<		<<		Sources		AV
	1<<		1<<		Info		Info
	>>1		>>1		Smart		Smart
	>>		>>		Exit		Exit
	1		1		Up		Up
	2		2		Down		Down
	3		3		Right		Right
	4		4		Left		Left
	5		5		OK		Ok
	6		6		Vol+		Vol +
	7		7		Vol-		Vol -



