




















































	Original	Rechange	Original	Rechange
	Power			Down / PR-
	Info			Right / Vol+
	Mute			Right / Vol+
	Picture			Left / Vol-
	V.Size			Left / Vol-
	Source			Menu
	Sound			Menu
	S.Mode			1
	Still			2
	Digest			3
	Pre.PR			4
	Sleep			5
	Text			6
	Exit			7
	Up / PR+			8
	Up / PR+			9
	Down / PR-			0



