











































































































Original	Rechange	Original	Rechange
 Power	 Power	 Green	 Green
 Mute	 Mute	 Yellow	 Yellow
 [> <]	 Subt	 Blue	 Blue
 Input	 AV	 [ ]	 TV/R
 1	 1	 [≡]	 Text
 2	 2	 MENU	 Menu
 3	 3	 Guide	 Guide
 4	 4	 Up	 Up
 5	 5	 Down	 Down
 6	 6	 Right	 Right
 7	 7	 Left	 Left
 8	 8	 OK	 Ok
 9	 9	 Vol+	 Vol +
 0	 0	 Vol-	 Vol -
 [i+]/[?]	 Info	 Prog+	 Ch +
 Recall/Play/Pause/Reverse	 Pre Ch	 Prog-	 Ch -
 Red	 Red		









































































	Original	Recharge	Original	Recharge
	Power			<<
	Mute			Play
	[> <]			Vol+
	Input			Vol-
	[i+]/[?]			
	♪			
	*			
	[+]			
	[ ]			
	Up			
	Down			
	Right			
	Left			
	OK			
	Pause			
	Stop			
	>>			





Original	Rechange	Original	Rechange
 Power	 Power	 *	 Format
 Mute	 Mute	 [+]	 3D
 [> <]	 Subt	 [ ]	 TV/R
 Input	 AV	 Up	 Up
 1	 1	 Down	 Down
 2	 2	 Right	 Right
 3	 3	 Left	 Left
 4	 4	 OK	 Ok
 5	 5	 Pause	 Pause
 6	 6	 Stop	 Stop
 7	 7	 >>	 >>
 8	 8	 <<	 <<
 9	 9	 Play	 Play
 0	 0	 Rec	 Rec
 [i+]/[?]	 Info	 Vol+	 Vol +
 -/--/Recall	 Pre Ch	 Vol-	 Vol -
 ♪	 Dual	 Prog+	 Ch +



