





































Original	Recharge
 On	 Power
 Off	 Shift + Power
 Mute	 Mute / Dimmer
 AVR	 Shift + Smart / List
 DVD	 Shift + 2
 VID1	 Shift + 1
 HDMI1	 Shift + Guide / EPG / -/-
 AM/FM	 Shift + 6
 CD	 Shift + 3
 VID2	 Shift + 4
 HDMI2	 Shift + 0
 AUX	 Shift + 7
 Tape	 Shift + 5
 VID3	 Shift + 8
 HDMI3	 Shift + Fav / Marker / PC
 Sleep	 Sleep / Timer
 6CH	 Shift + 9

Original	Recharge
 Vol+	 Vol+
 Surr.	 Eject / Surround
 Test	 Text / Goto
 Vol-	 Vol-
 CH.	 Guide / EPG / -/-
 Up	 Up
 SPKR	 Menu / Home
 Left	 Left
 OK	 OK
 Right	 Right
 Digital	 Picture / Format
 Down	 Down
 Delay	 Fav / Marker / PC
 1	 1
 2	 2
 3	 3
 4	 4





Original		Rechange	
	5		5
	6		6
	7		7
	8		8
	Tun-M		Smart / List
	9		9
	0		0
	Mem		Info / Angle
	Tuning ▲		>> / Tune+
	Direct		Back / Return
	Clear		Exit / Cancel / Clear
	Preset ▲		>> / Preset+
	Tuning ▼		<< / Tune-
	Tone		Setup / OPT /
	RDS		AV / Input / RDS
	Preset ▼		<< / Preset-
	Dolby Surr		Red / Netflix / Search

Original		Rechange	
	DTS Surr.		Green / APP / Repeat
	DTS Neo 6		Yellow / YouTube / Repeat
	Night		Shift + Sleep / Timer
	Logic 7		Shift + Blue / Prime
	Stereo		Blue / Prime Video / Random
	DIM		D.Menu / Top





Original		Rechange		Original		Rechange	
	Audio		Audio / Lang I/II		Pause DVD		Pause / Step / Freeze
	Subtitle		Subtitle / EQ				
	Disc Menu		D.Menu / Top				
	Setup		Setup / OPT /				
	Menu		Menu / Home				
	Status		Display / Media				
	Random		Blue / Prime Video / Random				
	Repeat		Green / APP / Repeat				
	A-B		Yellow / YouTube / Repeat				
	Playlist		Smart / List				
	I<</Skip Down		I<< / Preset-				
	Skip Up/>>I		>>I / Preset+				
	<< DVD		<< / Tune-				
	> DVD		Play / Slow				
	>> DVD		>> / Tune+				
	Open / Close		Eject / Surround				
	Stop DVD		Stop / Hold				

