


































	Original	Rechange	Original	Rechange
	Power	 Power		Pause
	Sleep	 Sleep		
	Mute	 Mute		
	Time	 Shift + AV		
	Alarm	 Smart		
	Source	 AV		
	Mem-	 Left		
	Mem	 Ok		
	Mem+	 Right		
	Back	 Back		
	Stop	 Stop		
	X	 Info		
	Vol+	 Vol +		
	Vol-	 Vol -		
	>>I	 >>I		
	I<<	 I<<		
	Play	 Play		

