





































Original	Recharge	Original	Recharge
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	List		List
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	CH+		Ch +
	CH-		Ch -

Original	Recharge	Original	Recharge
	Home/Recent		Smart
	Guide		Guide
	Back		Back
	Exit		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Wheel Up		>>I
	Wheel Down		I<<
	3D		3D
	Source		AV
	*		Options
	<<		<<
	Play		Play
	>>		>>





Original	Recharge	Original	Recharge
Pause	Pause		
Red	Red		
Green	Green		
Yellow	Yellow		
Blue	Blue		

