



Original		Recharge		Original		Recharge	
	Power		Power		Page Up		Shift + Vol + / Page +
	Freeze		Freeze / Timer		Page Down		Shift + Vol - / Page -
	Hide		Shift + Source		1/ <<		Shift + Left
	Aspect/Ratio		Eco / Aspect		2/Play/Pause		Shift + + / Play
	Resync		Shift + Power		3/Stop		- / Stop
	Source		Source		4/VGA		Help / Info
	Zoom		+ / Play		5/Component		3D / Invert
	Back		Shift + Menu		6/Video		Comp / Video
	Enter		Enter		7/SD/USB A		Shift + Comp / Video
	Up		Up		8/HDMI/DVI		Shift + Eco / Aspect
	Down		Down		9/LAN/WIFI		Volt / Focus
	Left		Left		0/USB B		Shift + 3D /
	Right		Right		>>		Shift + Up
	Menu		Menu		S-Video		Mode
	Vol+		Vol + / Page +				
	Vol-		Vol - / Page -				
	e		Auto				

