







































































Original		Recharge		Original		Recharge	
	On/Off		Power		Vol+		Vol+
	Mute		Mute / Dimmer		Vol-		Vol-
	1		1		CH+		CH+ / Page+
	2		2		CH-		CH- / Page-
	3		3		Menu		Menu / Home
	4		4		Exit		Exit / Cancel / Clear
	5		5		Back		Back / Return
	6		6		FAV		Fav / Marker / PC
	7		7		Up		Up
	8		8		Down		Down
	9		9		Left		Left
	0		0		Right		Right
	Tv Guide		Guide / EPG / -/-		OK		OK
	Recall		Shift + Back / Return		Info		Info / Angle
	Picture		Picture / Format		Text		Text / Goto
	Sound		Sound / Title		Subtitle		Subtitle / EQ
	Source		AV / Input / RDS		TV		TV/Radio /





Original	Recharge	Original	Recharge
 YouTube	 Yellow / YouTube / Repeat		
 Netflix	 Red / Netflix / Search		
 Smart	 Smart / List		
 Rec	 Rec / Rec Mode		
 I<<	 I<< / Preset-		
 >>I	 >>I / Preset+		
 Stop	 Stop / Hold		
 Rec.List	 Setup / OPT /		
 <<	 << / Tune-		
 >>	 >> / Tune+		
 Play	 Play / Slow		
 Pause	 Pause / Step / Freeze		
 Red/Goto	 Shift + Red / Netflix /		
 Green/A-B	 Green / APP / Repeat		
 Yellow/3D	 Shift + Yellow / YouTube /		
 Blue/Repaet	 Blue / Prime Video / Random		

