



| Original  |        | Rechange  |                   | Original  |             | Rechange  |                            |
|---|--------|---|-------------------|---|-------------|---|----------------------------|
|    | Power  |    | Power             |    | Vol-        |    | Vol-                       |
|    | Source |    | AV / Input / RDS  |    | Home        |    | Menu / Home                |
|    | 1      |    | 1                 |    | P-          |    | CH- / Page-                |
|    | 2      |    | 2                 |    | Guide       |    | Guide / EPG / -/-          |
|    | 3      |    | 3                 |    | Up          |    | Up                         |
|    | 4      |    | 4                 |    | i           |    | Info / Angle               |
|    | 5      |    | 5                 |    | Left        |    | Left                       |
|    | 6      |    | 6                 |    | OK          |    | OK                         |
|    | 7      |    | 7                 |    | Right       |    | Right                      |
|    | 8      |    | 8                 |    | Back        |    | Back / Return              |
|   | 9      |   | 9                 |   | Down        |   | Down                       |
|  | Lang   |  | Audio / Lang I/II |  | Exit        |  | Exit / Cancel / Clear      |
|  | 0      |  | 0                 |  | Netflix     |  | Shift + Red / Netflix /    |
|  | TXT    |  | Text / Goto       |  | YouTube     |  | Shift + Yellow / YouTube / |
|  | Vol+   |  | Vol+              |  | FPay        |  | Shift + Green / APP /      |
|  | Mute   |  | Mute / Dimmer     |  | prime video |  | Shift + Blue / Prime       |
|  | P+     |  | CH+ / Page+       |  | Red         |  | Red / Netflix / Search     |



