







































































Original	Rechange	Original	Rechange
 Standby / On	 Power	 Next / Fwd	 >> / Tune+
 Title	 Sound / Title	 Next / Fwd	 >> / Preset+
 Menu	 Menu / Home	 0	 0
 Open / Close	 Eject / Surround	 Clear	 Exit / Cancel / Clear
 OSD / Setup	 Setup / OPT /	 Search	 Red / Netflix / Search
 1	 1	 Pause / Step	 Pause / Step / Freeze
 2	 2	 Up	 Up
 3	 3	 Play	 Play / Slow
 Slow Fwd	 Shift + Slow Shift + Play /	 Left	 Left
 4	 4	 Enter	 OK
 5	 5	 Right	 Right
 6	 6	 Stop	 Stop / Hold
 Prev / Rev	 << / Tune-	 Down	 Down
 Prev / Rev	 << / Preset-	 Return	 Back / Return
 7	 7	 Play Mode	 Display / Media
 8	 8	 A-B	 Yellow / YouTube / Repeat
 9	 9	 Memory	 Fav / Marker / PC





Original	Recharge	Original	Recharge
TIMER	Timer	TIMER SLEEP	Sleep / Timer
EQUALIZER	Equalizer	SHIFT + EQ SUBTITLE	Shift + Subtitle / EQ
VOL / CH	Vol / CH	LIST SMART	Smart / List
	empty left	CH PAGE -	CH- / Page-
	empty right	CH PAGE +	CH+ / Page+
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
ANGLE	Angle	ANGLE INFO	Info / Angle
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II

