







































































































| Original | | Rechange | | Original | | Rechange | |
|---|-------------|---|---------------|---|---------------|---|-------------------|
|  | Power |  | Power |  | Music |  | 2 |
|  | Standby |  | Shift + Power |  | Entertain |  | 3 |
|  | CD |  | Shift + 3 |  | Movie |  | 4 |
|  | MD/CD-R |  | Shift + 5 |  | Standard |  | 5 |
|  | DVD |  | Shift + 2 |  | Select |  | 6 |
|  | DTV/CBL |  | Shift + 1 |  | Exto Sur. |  | 7 |
|  | Tuner |  | Shift + 6 |  | Pure Direct |  | 8 |
|  | Multi CH In |  | Shift + 8 |  | Speakers |  | 9 |
|  | V-AUX |  | Shift + 7 |  | Enhancer |  | 0 |
|  | DVR |  | Shift + 9 |  | Night |  | Guide / EPG / -/- |
|  | VCR |  | Shift + 4 |  | Straight |  | Fav / Marker / PC |
|  | PHONO |  | Shift + 0 |  | Level / Title |  | Sound / Title |
|  | Sleep |  | Sleep / Timer |  | Set Menu |  | Menu / Home |
|  | Volume + |  | Vol+ |  | Up |  | Up |
|  | Volume - |  | Vol- |  | Left/- |  | Left |
|  | Mute |  | Mute / Dimmer |  | Enter |  | OK |
|  | Stereo |  | 1 |  | Right/+ |  | Right |





















| Original | Rechange |
|---|--|
|  Power |  Power |
|  Standby |  Shift + Power |
|  CD |  Shift + 3 |
|  MD/CD-R |  Shift + 5 |
|  DVD |  Shift + 2 |
|  DTV/CBL |  Shift + 1 |
|  Tuner |  Shift + 6 |
|  Multi CH In |  Shift + 8 |
|  V-AUX |  Shift + 7 |
|  DVR |  Shift + 9 |
|  VCR |  Shift + 4 |
|  PHONO |  Shift + 0 |
|  Sleep |  Sleep / Timer |
|  Volume + |  Vol+ |
|  Volume - |  Vol- |
|  Mute |  Mute / Dimmer |
|  1 |  1 |

| Original | Rechange |
|---|---|
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  ENT |  Fav / Marker / PC |
|  Title/Level |  Sound / Title |
|  Up / Preset+ |  Up |
|  Up / Preset+ |  >> / Preset+ |
|  Menu/Set Menu |  Menu / Home |
|  Left / A/B/C/D/E- |  Left |
|  Enter |  OK |
|  Right / |  Right |



A/B/C/D/E+



| Original | Recharge | Original | Recharge |
|--|---|----------|----------|
|  Return |  Back / Return | | |
|  Down / Preset- |  Down | | |
|  Down / Preset- |  I<< / Preset- | | |
|  Display |  Display / Media | | |
|  Freq/Text |  Red / Netflix / Search | | |
|  PTY Seek Mode |  Yellow / YouTube / Repeat | | |
|  PTY Seek Start |  Blue / Prime Video / Random | | |
|  EON |  Green / APP / Repeat | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

