































Original	Rechange
 POWER	 Power
 TV/R	 TV/Radio /
 MUTE	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 SAT	 Shift + 0
 SAT	 Smart / List
 0	 0
 PAUSE	 Pause / Step / Freeze
 EPG	 Guide / EPG / -/--

Original	Rechange
 RED	 Red / Netflix / Search
 GREEN	 Green / APP / Repeat
 AUDIO	 Audio / Lang I/II
 YELLOW	 Yellow / YouTube / Repeat
 MENU	 Menu / Home
 ZOOM	 Zoom / Size
 BLUE	 Blue / Prime Video / Random
 EXIT	 Exit / Cancel / Clear
 LEFT	 Left
 VOL -	 Vol-
 UP	 Up
 CH+	 CH+ / Page+
 OK	 OK
 RIGHT	 Right
 VOL +	 Vol+
 CH-	 CH- / Page-
 DOWN	 Down





Original	Recharge
 Power	 Power
 Tv/R	 TV/Radio /
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 SAT	 Shift + 0
 0	 0
 Pause	 Pause / Step / Freeze
 Red	 Red / Netflix / Search
 EPG	 Guide / EPG / -/--

Original	Recharge
 Green	 Green / APP / Repeat
 Audio	 Audio / Lang I/II
 Yellow	 Yellow / YouTube / Repeat
 SUB	 Subtitle / EQ
 Menu	 Menu / Home
 Blue	 Blue / Prime Video / Random
 Zoom	 Zoom / Size
 Exit	 Exit / Cancel / Clear
 Vol-	 Vol-
 Left	 Left
 Up/CH+	 Up
 Right	 Right
 Vol+	 Vol+
 OK	 OK
 Down/CH-	 Down
 PgUp	 CH+ / Page+
 PgDn	 CH- / Page-



