



Original		Rechange		Original		Rechange	
	Power		Power		Green / Audio		Audio / Lang I/II
	1		1		Yellow / Subtitle		Yellow / YouTube / Repeat
	2		2		Yellow / Subtitle		Subtitle / EQ
	3		3		Menu		Menu / Home
	TV/SAT		Smart / List		Blue / UHF		Blue / Prime Video / Random
	4		4		Up		Up
	5		5		White / Timer		Sleep / Timer
	6		6		White / Timer		Fav / Marker / PC
	Radio		TV/Radio /		Left		Left
	7		7		OK		OK
	8		8		Right		Right
	9		9		Exit		Exit / Cancel / Clear
	Mute		Mute / Dimmer		Down		Down
	0		0		V+		Vol+
	Red / i		Info / Angle		P+		CH+ / Page+
	Red / i		Red / Netflix / Search		V-		Vol-
	Green / Audio		Green / APP / Repeat		?		D.Menu / Top



