






| Original | Rechange |
|--|---|
|  Mute |  Mute / Dimmer |
|  TV/SAT |  AV / Input / RDS |
|  Standby |  Power |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  Sat List |  Smart / List |
|  0 |  0 |
|  TV/R |  TV/Radio / |
|  CH-PG+ |  CH+ / Page+ |
|  EPG |  Guide / EPG / -/- |

| Original | Rechange |
|--|--|
|  Vol+ |  Vol+ |
|  CH/PG- |  CH- / Page- |
|  FAV |  Fav / Marker / PC |
|  Vol- |  Vol- |
|  Info |  Info / Angle |
|  Up |  Up |
|  Menu |  Menu / Home |
|  Left |  Left |
|  OK |  OK |
|  Right |  Right |
|  Back |  Back / Return |
|  Down |  Down |
|  Exit |  Exit / Cancel / Clear |
|  Red / Audio |  Red / Netflix / Search |
|  Red / Audio |  Audio / Lang I/II |
|  Green / Subt |  Green / APP / Repeat |
|  Green / Subt |  Subtitle / EQ |





| Original | Recharge | Original | Recharge |
|------------------------|--|----------|----------|
| TEXT Yellow / Text | GOTO TEXT Text / Goto | | |
| TEXT Yellow / Text | YouTube REPEAT A-B Yellow / YouTube / Repeat | | |
| SLEEP Blue / Sleep | Prime Video RANDOM Blue / Prime Video / Random | | |
| SLEEP Blue / Sleep | TIMER SLEEP Sleep / Timer | | |
| OPTION Option 1 | TOP MENU D.MENU D.Menu / Top | | |
| OPTION Option 2 | OPT-TOOLS SETUP Setup / OPT / | | |
| PAL/NTSC Pal / NTSC | FORMAT PICTURE Picture / Format | | |
| PAUSE Pause | HOLD Stop / Hold | | |
| PAUSE Freeze | STEP-FREEZE Pause / Step / Freeze | | |
| ZOOM Zoom | SIZE ZOOM Zoom / Size | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | Recharge |
|----------|----------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

