



































































Original	Recharge	Original	Recharge
	Power		Power
	Display		Display / Media
	Setup		Setup / OPT /
	Mute		Mute / Dimmer
	Menu		Menu / Home
	Music		Red / Netflix / Search
	Copy		Info / Angle
	Zoom		Zoom / Size
	Tv System		TV/Radio /
	Browser		D.Menu / Top
	Vol-		Vol-
	Vol+		Vol+
	Guide		Guide / EPG / -/-
	Return		Back / Return
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Down		Down
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Time Shift		Sound / Title
	0		0
	Goto		Text / Goto
	Rec		Rec / Rec Mode
	Play		Play / Slow
	Stop		Stop / Hold





Original	Recharge	Original	Recharge
Timer	Sleep / Timer		
Pause/Step	Pause / Step / Freeze		
I>/Slow	Fav / Marker / PC		
I<</Prev	I<< / Preset-		
ReclList	Smart / List		
←/INS Replay	CH- / Page-		
→/CM Skip	CH+ / Page+		
>>I/Next	>>I / Preset+		
A-B	Yellow / YouTube / Repeat		
Subtitle	Subtitle / EQ		
Repeat	Green / APP / Repeat		
<</FR	<< / Tune-		
F1	Blue / Prime Video / Random		
Source	AV / Input / RDS		
Audio	Audio / Lang I/II		
>>/FF	>> / Tune+		

