



| Original  | Recharge  | Original   | Recharge  |
|---|---|--|---|
|  Green/Timer |  Green / APP / Repeat        |  Down/P-  |  Down                |
|  Power       |  Power                       |  P-       |  CH- / Page-         |
|  Yellow      |  Yellow / YouTube / Repeat   |  Menu     |  Menu / Home         |
|  Red/Audio   |  Red / Netflix / Search      |  OK       |  OK                  |
|  Blue        |  Blue / Prime Video / Random |  Help/?   |  Smart / List        |
|  Colour-     |  << / Tune-                  |  1        |  1                   |
|  Colour+     |  >> / Tune+                  |  2        |  2                   |
|  Brightness- |  I<< / Preset-               |  3        |  3                   |
|  Brightness+ |  >>I / Preset+               |  4        |  4                   |
|  TV         |  TV/Radio /                 |  5       |  5                  |
|  Display   |  Display / Media           |  6      |  6                 |
|  Up/P+     |  Up                        |  7      |  7                 |
|  P+        |  CH+ / Page+               |  8      |  8                 |
|  Left/V-   |  Left                      |  9      |  9                 |
|  V-        |  Vol-                      |  Top 10 |  Fav / Marker / PC |
|  Right/V+  |  Right                     |  0/AV   |  0                 |
|  V+        |  Vol+                      |  Mute   |  Mute / Dimmer     |

