





























































Original	Rechange
 VTR	 Power
 Clock/Counter	 Fav / Marker / PC
 Timer Rec	 Display / Media
 +/-	 Back / Return
 Time Search	 Sleep / Timer
 Memory/Search	 Smart / List
 1	 1
 2	 2
 3	 3
 Reset	 Exit / Cancel / Clear
 4	 4
 5	 5
 6	 6
 Check/Prog	 TV/Radio /
 7	 7
 8	 8
 9	 9

Original	Rechange
 Next	 >> / Preset+
 VPS	 Zoom / Size
 10/0	 0
 -/--	 Guide / EPG / -/--
 Rec	 Rec / Rec Mode
 Pause/Still	 Pause / Step / Freeze
 Stop	 Stop / Hold
 II>/Still ADV	 Blue / Prime Video / Random
 <</REW	 << / Tune-
 Play	 Play / Slow
 >>/FF	 >> / Tune+
 Slow-	 Left
 Slow	 OK
 Slow+	 Right

