



Original	Recharge	Original	Recharge
Guide	Guide / EPG / -/--	0	0
↔/Interactive	Menu / Home	Radio	TV/Radio /
[: :]/Cinema	Display / Media	Back	Back / Return
Power	Power	Red	Red / Netflix / Search
1	1	Green	Green / APP / Repeat
2	2	Yellow	Yellow / YouTube / Repeat
3	3	Blue	Blue / Prime Video / Random
>>/Goto	>> / Tune+	Vol+	Vol+
4	4	Up	Up
5	5	CH+	CH+ / Page+
6	6	Left	Left
i/Details	Info / Angle	OK	OK
7	7	Right	Right
8	8	Vol-	Vol-
9	9	Down	Down
?/Help	Smart / List	CH-	CH- / Page-
TV	AV / Input / RDS	Mute	Mute / Dimmer

Original	Recharge	Original	Recharge
0	0	0	0
Radio	TV/Radio /	Back	Back / Return
Red	Red / Netflix / Search	Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat	Blue	Blue / Prime Video / Random
Vol+	Vol+	Up	Up
CH+	CH+ / Page+	Left	Left
OK	OK	Right	Right
Vol-	Vol-	Down	Down
CH-	CH- / Page-	Mute	Mute / Dimmer



