



| Original  | Rechange   |
|---|--|
|  Power     |  Power                |
|  1         |  1                    |
|  2         |  2                    |
|  3         |  3                    |
|  4         |  4                    |
|  5         |  5                    |
|  6         |  6                    |
|  7         |  7                    |
|  8         |  8                    |
|  9         |  9                    |
|  0        |  0                   |
|  Liste   |  Smart / List       |
|  EPG     |  Guide / EPG / -/-- |
|  PPV     |  D.Menu / Top       |
|  Dienste |  Display / Media    |
|  Up      |  Up                 |
|  Left    |  Left               |

| Original   | Rechange  |
|--|---|
|  OK           |  OK                            |
|  Right        |  Right                         |
|  Down         |  Down                          |
|  P+           |  CH+ / Page+                   |
|  Zurück       |  Back / Return                 |
|  Vol+         |  Vol+                          |
|  P-           |  CH- / Page-                   |
|  Esc / TV     |  Exit / Cancel / Clear         |
|  Vol-         |  Vol-                          |
|  Text         |  Text / Goto                   |
|  Mute        |  Mute / Dimmer                |
|  Red        |  Red / Netflix / Search      |
|  Green      |  Green / APP / Repeat        |
|  Yellow     |  Yellow / YouTube / Repeat   |
|  Blue       |  Blue / Prime Video / Random |
|  TV / Radio |  TV/Radio /                  |
|  Opt        |  Setup / OPT /               |



