

























Original	Recharge	Original	Recharge
 Back	 Back / Return		
 Down	 Down		
 Exit	 Exit / Cancel / Clear		
 Sleep	 Sleep / Timer		
 Stop	 Stop / Hold		
 <<	 << / Tune-		
 Play	 Play / Slow		
 Pause	 Pause / Step / Freeze		
 >>	 >> / Tune+		
 .	 Red / Netflix / Search		
 ..	 Green / APP / Repeat		
 ::	 Yellow / YouTube / Repeat		
 ::	 Blue / Prime Video / Random		

