





















































Original	Rechange
 Power	 Power
 Mute	 Mute / Dimmer
 Play/Pause	 Play / Slow
 I<	 I<< / Preset-
 >I	 >>I / Preset+
 Movie	 Picture / Format
 Night	 Sleep / Timer
 HDMI ARC	 Setup / OPT /
 Voice	 Sound / Title
 Music	 Audio / Lang I/II
 Bass+	 Up
 Audio Sync -	 Left
 Audio Sync +	 Right
 Bass-	 Down
 Vol+	 Vol+
 Treble+	 CH+ / Page+
 Vol-	 Vol-

Original	Rechange
 Treble-	 CH- / Page-
 Coax	 1
 Optical	 2
 Audio In	 Smart / List
 Aux	 7
 USB	 8
 Bluetooth	 9
 DIM	 Shift + Mute / Dimmer

