














| Original | Rechange |
|--|--|
|  Power |  Power |
|  Open/Close |  Eject / Surround |
|  Scan |  Display / Media |
|  Swap |  Back / Return |
|  Call |  Shift + OK |
|  Mute |  Mute / Dimmer |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  -/-- |  Guide / EPG / -/-- |

| Original | Rechange |
|---|---|
|  TV/AV |  AV / Input / RDS |
|  P+ |  CH+ / Page+ |
|  TV/DVD |  Smart / List |
|  V- |  Vol- |
|  Menu |  Menu / Home |
|  V+ |  Vol+ |
|  Exit |  Exit / Cancel / Clear |
|  P- |  CH- / Page- |
|  P.STD |  Picture / Format |
|  Red/Picture |  Shift + Picture / Format |
|  Red/Picture |  Red / Netflix / Search |
|  Green/Sound |  Sound / Title |
|  Green/Sound |  Green / APP / Repeat |
|  Yellow/Time |  Yellow / YouTube / Repeat |
|  Blue/Function |  Blue / Prime Video / Random |
|  << |  << / Tune- |
|  >> |  >> / Tune+ |







































| Original | Rechange |
|--------------|-----------------------------|
| Power | Power |
| Open / Close | Eject / Surround |
| Scan | Shift + Setup / OPT / Tools |
| Swap | Back / Return |
| Call | Smart / List |
| Mute | Mute / Dimmer |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| 0 | 0 |
| -/-- | Guide / EPG / -/-- |

| Original | Rechange |
|---------------|---------------------------|
| TV/AV | AV / Input / RDS |
| I-II | Shift + Audio / Lang I/II |
| P+ | CH+ / Page+ |
| TV/DVD | Shift + 2 |
| TV/DVD | Shift + 1 |
| V- | Vol- |
| Menu | Menu / Home |
| V+ | Vol+ |
| Exit | Exit / Cancel / Clear |
| P- | CH- / Page- |
| P.Std | Picture / Format |
| Red / Picture | Red / Netflix / Search |
| Red / Picture | Shift + Picture / Format |
| Green / Sound | Green / APP / Repeat |
| Green / Sound | Shift + Sound / Title |
| Yellow / Time | Yellow / YouTube / Repeat |
| Yellow / Time | Sleep / Timer |











| Original | Recharge |
|---|--|
|  Blue / Function |  Blue / Prime Video / Random |
|  Rev |  << / Tune- |
|  Fwd |  >> / Tune+ |
|  I<< |  I<< / Preset- |
|  >>I |  >>I / Preset+ |
|  Stop |  Stop / Hold |
|  Setup |  Setup / OPT / |
|  Pause / Step |  Pause / Step / Freeze |
|  White / Tune |  Display / Media |
|  D.Menu |  D.Menu / Top |
|  Up |  Up |
|  Repeat |  Shift + Green / APP / |
|  A-B |  Shift + Yellow / YouTube / |
|  Left |  Left |
|  Play / Enter |  Play / Slow |
|  Play / Enter |  OK |
|  Right |  Right |

| Original | Recharge |
|---|---|
|  Slow |  Shift + Play / |
|  Angle |  Info / Angle |
|  Down |  Down |
|  Title / PBC |  Sound / Title |
|  Search |  Shift + Red / Netflix / |
|  Audio |  Audio / Lang I/II |
|  Program |  TV/Radio / |
|  Zoom |  Zoom / Size |
|  D.Call |  Shift + Smart / List |
|  10+ |  Shift + Guide / EPG / -/- |
|  Caption |  Subtitle / EQ |
|  Hold |  Shift + Stop / |
|  [-] |  Shift + TV/Radio / Program |
|  Mix |  Shift + Text / |
|  Text |  Text / Goto |
|  [X] |  Shift + Exit / Cancel / Clear |
|  Reveal |  Shift + Sleep / Timer |





| Original | Recharge | |
|---|----------|--|
|  | Size |  Shift + Zoom / |
|  | Subcode |  Shift + Subtitle / EQ |
|  | > |  Shift + Eject / Surround |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

| Original | Recharge |
|----------|----------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

