




| Original                                                                                  | Recharge                                                                                                                                                                            | Original                                                                                          | Recharge                                                                                                                                                                                                    |
|-------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  Tuner   |  Red / Netflix / Search                                                                            |  6 VCR         |  +  Shift + 6                         |
|  CD      |  Yellow / YouTube / Repeat                                                                         |  7 TV          |  7                                                                                                                       |
|  Tape    |  Blue / Prime Video / Random                                                                       |  7 VCR         |  +  Shift + 7                         |
|  TV      |  TV/Radio /                                                                                        |  8 TV          |  8                                                                                                                       |
|  CDV     |  Zoom / Size                                                                                       |  8 VCR         |  +  Shift + 8                         |
|  VCR     |  Green / APP / Repeat                                                                              |  9 TV          |  9                                                                                                                       |
|  1 TV    |  1                                                                                                 |  9 VCR         |  +  Shift + 9                         |
|  1 VCR   |  +  Shift + 1     |  Memo TV       |  Guide / EPG / -/-                                                                                                       |
|  2 TV    |  2                                                                                                 |  Memo VCR      |  +  Shift + Guide / EPG / -/-         |
|  2 VCR   |  +  Shift + 2     |  0 TV          |  0                                                                                                                       |
|  3 TV  |  3                                                                                               |  0 VCR       |  +  Shift + 0                     |
|  3 VCR |  +  Shift + 3 |  Clear TV    |  Exit / Cancel / Clear                                                                                                 |
|  4 TV  |  4                                                                                               |  Clear VCR   |  +  Shift + Exit / Cancel / Clear |
|  4 VCR |  +  Shift + 4 |  </A-Scan TV |  Left                                                                                                                  |
|  5 TV  |  5                                                                                               |  Mode/Random |  Smart / List                                                                                                          |
|  5 VCR |  +  Shift + 5 |  P:P/> TV    |  Right                                                                                                                 |
|  6 TV  |  6                                                                                               |  P:P/> VCR   |  +  Shift + Right                 |











| Original                                                                                    | Recharge                                                                                                      |
|---------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------|
|  Tuner     |  Red / Netflix / Search      |
|  CD        |  Yellow / YouTube / Repeat   |
|  Tape      |  Blue / Prime Video / Random |
|  TV        |  TV/Radio /                  |
|  CDV       |  Zoom / Size                 |
|  VCR       |  Green / APP / Repeat        |
|  1 CD      |  1                           |
|  2 CD      |  2                           |
|  3 CD      |  3                           |
|  4 CD      |  4                           |
|  5 CD      |  5                           |
|  6 CD    |  6                         |
|  7 CD    |  7                         |
|  8 CD    |  8                         |
|  9 CD    |  9                         |
|  Memo CD |  Guide / EPG / -/--        |
|  0 CD    |  0                         |


| Original                                                                                           | Recharge                                                                                                  |
|----------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------|
|  Clear CD       |  Exit / Cancel / Clear |
|  Mode/Random    |  Smart / List          |
|  Preset Up CD   |  Up                    |
|  Disc Up CD     |  CH+ / Page+           |
|  Vol+ CD        |  Vol+                  |
|  Preset Down CD |  Down                  |
|  Disc Down CD   |  CH- / Page-           |
|  Vol- CD        |  Vol-                  |
|  Stop CD        |  Stop / Hold           |
|  Pause CD       |  Pause / Step / Freeze |
|  Play CD        |  Play / Slow           |
|  ↔ CD         |  Picture / Format    |
|  << CD        |  << / Tune-          |
|  >> CD        |  >> / Tune+          |
|  STBY CD      |  Power               |






| Original                                                                                    | Recharge                                                                                                      | Original                                                                                              | Recharge                                                                                                            |
|---------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------|
|  Tuner     |  Red / Netflix / Search      |  6 CDV             |  Shift + 6                       |
|  CD        |  Yellow / YouTube / Repeat   |  7 Tuner           |  7                               |
|  Tape      |  Blue / Prime Video / Random |  7 CDV             |  Shift + 7                       |
|  TV        |  TV/Radio /                  |  8 Tuner           |  8                               |
|  CDV       |  Zoom / Size                 |  8 CDV             |  Shift + 8                       |
|  VCR       |  Green / APP / Repeat        |  9 Tuner           |  9                               |
|  1 Tuner   |  1                           |  9 CDV             |  Shift + 9                       |
|  1 CDV     |  Shift + 1                   |  Memo Tuner        |  Guide / EPG / -/-               |
|  2 Tuner   |  2                           |  Memo CDV          |  Shift + Guide / EPG / -/-       |
|  2 CDV     |  Shift + 2                   |  0 Tuner           |  0                               |
|  3 Tuner |  3                         |  0 CDV           |  Shift + 0                     |
|  3 CDV   |  Shift + 3                 |  Clear Tuner     |  Exit / Cancel / Clear         |
|  4 Tuner |  4                         |  Clear CDV       |  Shift + Exit / Cancel / Clear |
|  4 CDV   |  Shift + 4                 |  </A-Scan Tuner  |  Left                          |
|  5 Tuner |  5                         |  Mode/Random     |  Smart / List                  |
|  5 CDV   |  Shift + 5                 |  Mode/Random     |  Shift + Smart / List          |
|  6 Tuner |  6                         |  Preset Up Tuner |  Up                            |







| Original                                                                                      | Recharge                                                                                                      |
|-----------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------|
|  Tuner       |  Red / Netflix / Search      |
|  CD          |  Yellow / YouTube / Repeat   |
|  Tape        |  Blue / Prime Video / Random |
|  TV          |  TV/Radio /                  |
|  CDV         |  Zoom / Size                 |
|  VCR         |  Green / APP / Repeat        |
|  1 Tape      |  1                           |
|  2 Tape      |  2                           |
|  3 Tape      |  3                           |
|  4 Tape      |  4                           |
|  5 Tape    |  5                         |
|  6 Tape    |  6                         |
|  7 Tape    |  7                         |
|  8 Tape    |  8                         |
|  9 Tape    |  9                         |
|  Memo Tape |  Guide / EPG / -/-         |
|  0 Tape    |  0                         |

| Original                                                                                             | Recharge                                                                                                  |
|------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------|
|  Clear Tape       |  Exit / Cancel / Clear |
|  </A-Scan Tape    |  Left                  |
|  Mode/Random      |  Smart / List          |
|  P:P/> Tape       |  Right                 |
|  Preset Up Tape   |  Up                    |
|  Vol+ Tape        |  Vol+                  |
|  Preset Down Tape |  Down                  |
|  Vol- Tape        |  Vol-                  |
|  Stop Tape        |  Stop / Hold           |
|  Pause Tape       |  Pause / Step / Freeze |
|  Play Tape      |  Play / Slow         |
|  ↔ Tape         |  Picture / Format    |
|  << Tape        |  << / Tune-          |
|  >> Tape        |  >> / Tune+          |
|  TXT Tape       |  Text / Goto         |
|  Rec Tape       |  Rec / Rec Mode      |
|  STBY Tape      |  Power               |

