




























| Original   | Recharge  | Original | Recharge  |
|------------|---|----------|---|
| On/Off     |  Power         | 5        |  5                           |
| Mute       |  Mute / Dimmer | 6        |  6                           |
| Return TV  |  TV/Radio /    | 7        |  7                           |
| Menu       |  Menu / Home   | 8        |  8                           |
| Menu Up    |  Up            | 9        |  9                           |
| Menu Left  |  Left          | 0/10     |  0                           |
| OK Enter   |  OK            | Red      |  Red / Netflix / Search      |
| Menu Right |  Right         | Green    |  Green / APP / Repeat        |
| Menu Down  |  Down          | Yellow   |  Yellow / YouTube / Repeat   |
| Volume+    |  Vol+          | Blue     |  Blue / Prime Video / Random |
| Chan.Up    |  CH+ / Page+  |          |   |
| Volume-    |  Vol-        |          |   |
| Chan.Down  |  CH- / Page- |          |   |
| 1          |  1           |          |   |
| 2          |  2           |          |   |
| 3          |  3           |          |   |
| 4          |  4           |          |   |

