









































































































	Original	Rechange		Original	Rechange
	Power		Power		PR-
	Red		Red		Ch -
	Green/Cass.		Green		1
	Yellow/Prog		Yellow		2
	Blue/Mem		Blue		3
	Violet/Status		Smart		4
	Exit		Exit		5
	Menu		Menu		6
	Up		Up		7
	Down		Down		8
	Right		Right		9
	Left		Left		0
	OK		Ok		AV
	Vol+		Vol +		AV
	Vol-		Vol -		Info
	Mute		Mute		Media
	PR+		Ch +		Format
					Index/Mark
					0000
					SP/LP
					<<
					Play





	Original	Recharge		Original	Recharge
	Power		Power		PR-
	Red		Red		1
	Green/Cass.		Green		2
	Yellow/Prog		Yellow		3
	Blue/Mem		Blue		4
	Violet/Status		Smart		5
	Menu		Menu		6
	Exit		Exit		7
	Up		Up		8
	Down		Down		9
	Right		Right		0
	Left		Left		AV
	OK		Ok		
	Vol+		Vol +		
	Vol-		Vol -		
	Mute		Mute		
	PR+		Ch +		

