







































































| Original  |              | Rechange  |                       | Original  |          | Rechange  |                   |
|---|--------------|---|-----------------------|---|----------|---|-------------------|
|    | Power        |    | Power                 |    | 7        |    | 7                 |
|    | Text         |    | Text / Goto           |    | 8        |    | 8                 |
|    | △            |    | Setup / OPT /         |    | 9        |    | 9                 |
|    | Help         |    | Zoom / Size           |    | Back     |    | Back / Return     |
|    | Rec          |    | Rec / Rec Mode        |    | 0        |    | 0                 |
|    | D.Menu / Top |    | D.Menu / Top          |    | Enter    |    | Fav / Marker / PC |
|    | Stop         |    | Stop / Hold           |    | Vol+     |    | Vol+              |
|    | <<           |    | << / Tune-            |    | Language |    | Audio / Lang I/II |
|    | Play / Pause |    | Play / Slow           |    | CH+      |    | CH+ / Page+       |
|   | Play / Pause |   | Pause / Step / Freeze |   | Vol-     |   | Vol-              |
|  | >>           |  | >> / Tune+            |  | Mute     |  | Mute / Dimmer     |
|  | 1            |  | 1                     |  | CH-      |  | CH- / Page-       |
|  | 2            |  | 2                     |  | Guide    |  | Guide / EPG / -/- |
|  | 3            |  | 3                     |  | Up       |  | Up                |
|  | 4            |  | 4                     |  | Info     |  | Info / Angle      |
|  | 5            |  | 5                     |  | Left     |  | Left              |
|  | 6            |  | 6                     |  | OK       |  | OK                |









































































| Original |            | Recharge |                             |
|----------|------------|----------|-----------------------------|
|          | Right      |          | Right                       |
|          | Menu       |          | Menu / Home                 |
|          | Down       |          | Down                        |
|          | Exit       |          | Exit / Cancel / Clear       |
|          | Red        |          | Red / Netflix / Search      |
|          | Green      |          | Green / APP / Repeat        |
|          | Yellow     |          | Yellow / YouTube / Repeat   |
|          | Blue       |          | Blue / Prime Video / Random |
|          | Digital TV |          | Smart / List                |
|          | Movie      |          | Picture / Format            |
|          | Radio      |          | TV/Radio /                  |
|          | Media      |          | Display / Media             |
|          |            |          |                             |
|          |            |          |                             |
|          |            |          |                             |
|          |            |          |                             |
|          |            |          |                             |

| Original |  | Recharge |  |
|----------|--|----------|--|
|          |  |          |  |
|          |  |          |  |
|          |  |          |  |
|          |  |          |  |
|          |  |          |  |
|          |  |          |  |
|          |  |          |  |
|          |  |          |  |
|          |  |          |  |
|          |  |          |  |
|          |  |          |  |
|          |  |          |  |
|          |  |          |  |
|          |  |          |  |
|          |  |          |  |
|          |  |          |  |

























| Original  |              | Rechange  |                       | Original  |          | Rechange  |                   |
|---|--------------|---|-----------------------|---|----------|---|-------------------|
|    | Power        |    | Power                 |    | 7        |    | 7                 |
|    | Text         |    | Text / Goto           |    | 8        |    | 8                 |
|    | △            |    | Setup / OPT /         |    | 9        |    | 9                 |
|    | Help         |    | Zoom / Size           |    | Back     |    | Back / Return     |
|    | Rec          |    | Rec / Rec Mode        |    | 0        |    | 0                 |
|    | D.Menu / Top |    | D.Menu / Top          |    | Enter    |    | Fav / Marker / PC |
|    | Stop         |    | Stop / Hold           |    | Vol+     |    | Vol+              |
|    | <<           |    | << / Tune-            |    | Language |    | Audio / Lang I/II |
|    | Play / Pause |    | Play / Slow           |    | CH+      |    | CH+ / Page+       |
|   | Play / Pause |   | Pause / Step / Freeze |   | Vol-     |   | Vol-              |
|  | >>           |  | >> / Tune+            |  | Mute     |  | Mute / Dimmer     |
|  | 1            |  | 1                     |  | CH-      |  | CH- / Page-       |
|  | 2            |  | 2                     |  | Guide    |  | Guide / EPG / -/- |
|  | 3            |  | 3                     |  | Up       |  | Up                |
|  | 4            |  | 4                     |  | Info     |  | Info / Angle      |
|  | 5            |  | 5                     |  | Left     |  | Left              |
|  | 6            |  | 6                     |  | OK       |  | OK                |





| Original   | Recharge  |
|--|---|
|  Right      |  Right                       |
|  Menu       |  Menu / Home                 |
|  Down       |  Down                        |
|  Exit       |  Exit / Cancel / Clear       |
|  Red        |  Red / Netflix / Search      |
|  Green      |  Green / APP / Repeat        |
|  Yellow     |  Yellow / YouTube / Repeat   |
|  Blue       |  Blue / Prime Video / Random |
|  Digital TV |  Smart / List                |
|  Movie      |  Picture / Format            |
|  Radio      |  TV/Radio /                  |
|  Media     |  Display / Media            |
|  |   |
|  |   |
|  |   |
|  |   |
|  |   |
|  |   |
|  |   |
|  |   |
|  |   |
|  |   |
|  |   |

| Original | Recharge |
|----------|----------|
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |
|          |          |

