





































































Original		Rechange		Original		Rechange	
	Power		Power		Language		Dual
	Display		Info		Up		Up
	File		Format		Down		Down
	Menu Disc		D. Menu		Right		Right
	Eject Disc		Eject		Left		Left
	Repeat		List		OK		Ok
	Shuffle		Sleep		Vol +		Vol +
	Zoom		Shift + Eject		Vol -		Vol -
	<<		<<		Home		Shift + Smart
	Stop		Stop		Mute		Mute
	>>		>>		Back		Back
	I<		I<<		NAS		AV
	Play / Pause		Play		Movie		1
	>I		>>I		Music		2
	Option		Options		Photo		3
	Setup		Menu		Internet		Smart
	Caption		Subt				

