










	Original	Rechange		Original	Rechange
	Power		Power		FAV
	Mute		Mute		Pre Ch
	1		1		Page+
	2		2		Page-
	3		3		Up/CH+
	4		4		Down/CH-
	5		5		Right
	6		6		Left
	7		7		OK
	8		8		Vol+
	9		9		Vol-
	0		0		Red
	Info		Info		Green
	Recall		Back		Yellow
	Menu		Menu		Blue
	EPG		Guide		Audio
	Exit		Exit		Pause
					TTX
					Text



