



































































	Original	Rechange		Original	Rechange
	Power		Power		7
	Mute		Mute		8
	TV		TV/R		9
	Input		AV		0
	MPX		Smart		Recall
	Sleep		Sleep		Display
	Up		Up		CH+
	Down		Down		CH-
	Right		Right		Vol+
	Left		Left		Vol-
	Menu		Menu		Red
	1		1		Green
	2		2		Yellow
	3		3		Blue
	4		4		Text
	5		5		Hold
	6		6		Size
					Back
					Info
					Ch +
					Ch -
					Vol +
					Vol -
					Red
					Green
					Yellow
					Blue
					Text
					3D
					Format





	Original	Recharge
	Sub Page	Subt
	Index	List
	Reveal	Options
	Mix	Dual

	Original	Recharge

