




















































































	Original	Rechange		Original	Rechange
	Power		Power		Angle / TTX
	Mute		Mute		Audio
	Source		AV		PBC / Scan
	Eject		Eject		Title
	1		1		Stop
	2		2		Play / Pause
	3		3		Play / Pause
	4		4		Up
	5		5		Left
	6		6		Enter
	7		7		Right
	8		8		Down
	9		9		Mode
	0		0		Setup
	10+		Shift + Guide		Zoom / Yellow
	GOTO		Smart		Zoom / Yellow
	Subtitle		Subt		Shift + Eject
			Text		Text
			Dual		Dual
			Media		Media
			List		List
			Play		Play
			Pause		Pause
			Up		Up
			Left		Left
			Ok		Ok
			Right		Right
			Down		Down
			Format		Format
			Options		Options
			Yellow		Yellow
			Menu		Menu



