





















| Original | | Rechange | | Original | | Rechange | |
|---|--------|---|-------|---|--------------|---|----------------|
|  | Power |  | Power |  | Auto |  | Smart |
|  | Mute |  | Mute |  | CH+ |  | Ch + |
|  | 1 |  | 1 |  | CH- |  | Ch - |
|  | 2 |  | 2 |  | Display |  | Info |
|  | 3 |  | 3 |  | TV / Radio |  | TV/R |
|  | 4 |  | 4 |  | Up |  | Up |
|  | 5 |  | 5 |  | Down |  | Down |
|  | 6 |  | 6 |  | Left |  | Left |
|  | 7 |  | 7 |  | Right |  | Right |
|  | 8 |  | 8 |  | OK / CH List |  | Ok |
|  | 9 |  | 9 |  | OK / CH List |  | List |
|  | 0 |  | 0 |  | Menu |  | Menu |
|  | -/-- |  | Guide |  | Exit |  | Exit |
|  | Recall |  | Back |  | Source |  | AV |
|  | Vol+ |  | Vol + |  | P.Mode |  | Shift + Format |
|  | Vol- |  | Vol - |  | S.Mode |  | Shift + Dual |
|  | Rec |  | Rec |  | Sleep |  | Sleep |





| Original | | Rechange | | Original | | Rechange | |
|---|------------------------|---|--------------|---|--------|---|--------|
|  | Text |  | Text |  | Red |  | Red |
|  | Hold |  | Shift + Stop |  | Green |  | Green |
|  | Index |  | D. Menu |  | Yellow |  | Yellow |
|  | Size |  | Eject |  | Blue |  | Blue |
|  | FAV |  | Pre Ch | | | | |
|  | Subpage |  | Shift + Subt | | | | |
|  | Play/Pause / Timeshift |  | Play | | | | |
|  | Play/Pause / Timeshift |  | Pause | | | | |
|  | Audio |  | Dual | | | | |
|  | Stop |  | Stop | | | | |
|  | Reveal |  | Media | | | | |
|  | Aspect |  | Format | | | | |
|  | Subtitle |  | Subt | | | | |
|  | << |  | << | | | | |
|  | >> |  | >> | | | | |
|  | << |  | << | | | | |
|  | >> |  | >> | | | | |

