







































































| Original  |            | Rechange  |              | Original  |            | Rechange  |                             |
|---|------------|---|--------------|---|------------|---|-----------------------------|
|    | Power      |    | Power        |    | P < P      |    | Display / Media             |
|    | Up         |    | Up           |    | 0          |    | 0                           |
|    | Left       |    | Left         |    | Aspect     |    | Picture / Format            |
|    | Right      |    | Right        |    | Swap       |    | Back / Return               |
|    | Down       |    | Down         |    | P - / CH - |    | CH- / Page-                 |
|    | M Menu     |    | Menu / Home  |    | P + / CH + |    | CH+ / Page+                 |
|    | [ i ] Info |    | Info / Angle |    | Vol -      |    | Vol-                        |
|    | OK         |    | OK           |    | Vol +      |    | Vol+                        |
|    | 1          |    | 1            |    | Mute       |    | Mute / Dimmer               |
|    | 2          |    | 2            |    | I - II     |    | Audio / Lang I/II           |
|   | 3          |   | 3            |   | [ TV ]     |   | Smart / List                |
|  | 4          |  | 4            |  | Source     |  | AV / Input / RDS            |
|  | 5          |  | 5            |  | Red / PIP  |  | Red / Netflix / Search      |
|  | 6          |  | 6            |  | Green      |  | Green / APP / Repeat        |
|  | 7          |  | 7            |  | Yellow     |  | Yellow / YouTube / Repeat   |
|  | 8          |  | 8            |  | Blue       |  | Blue / Prime Video / Random |
|  | 9          |  | 9            |  | Text       |  | Text / Goto                 |





|   | Original | Rechange   | Original | Rechange |
|---|----------|--|----------|----------|
|  | Timer    |  Sleep / Timer  |          |          |
|  | Hold     |  Stop / Hold  |          |          |
|  | Cancel   |  Exit / Cancel / Clear  |          |          |
|  | Mix      |  +  Shift + Text / |          |          |
|  | Size     |  Zoom / Size  |          |          |
|  | Help     |  Setup / OPT /  |          |          |
|  | Index    |  D.Menu / Top   |          |          |
|   |          |  |          |          |
|   |          |  |          |          |
|   |          |  |          |          |
|   |          |  |          |          |
|   |          |  |          |          |
|   |          |  |          |          |
|   |          |  |          |          |
|   |          |  |          |          |
|   |          |  |          |          |
|   |          |  |          |          |
|   |          |  |          |          |
|   |          |  |          |          |
|   |          |  |          |          |

