























































	Original	Rechange		Original	Rechange
	Standby		Power		Search
	Menu		Menu		TV/R
	Title		Options		Stop
	Setup		Sleep		Pause
	Up		Up		Repeat
	Down		Down		Zoom
	Right		Right		Slow
	Left		Left		A-B
	>>		>>		Vol+
	<<		<<		Vol-
	>>		>>		1
	<<		<<		2
	Subtitle		Subt		3
	Angle		Guide		4
	Audio		Dual		5
	Play		Play		6
	Display		Info		7
					8



