


















	Original	Rechange	Original	Rechange
	Power			
 AUX	Bluetooth / AUX	 7		
 AUX	Bluetooth / AUX	 9		
1	1	 1		
2	2	 2		
3	3	 3		
4	4	 4		
5	5	 5		
6	6	 6		
 +	Vol+			
	Play / Pause			
	Play / Pause			
 -	Vol-			
 <<	I<<			
 >>	>>I			
	Dislike			
	Like			

